

# Important Notice

## Using LogiCO2 Mk9 O2 Detectors to monitor O2 when using Nitrogen Generators

When using a Nitrogen Generator, the oxygen created by the generator needs to be led out of the area. Not only is it a potential fire hazard to have an increased amount of oxygen in the area, it is also not allowed to use the LogiCO2 Mk9 O2 Detector.

The O2 detector uses the fresh air in the room as a reference and regularly calibrates itself in reference to it. If the fresh air contains unnaturally high levels of O2, the reference will be incorrect and the O2 detector will calibrate incorrectly. Therefore it is essential to lead the oxygen out of the monitored space.